



X6000



- 1: Fill Cap 2: Black Lid 3: BPA free Container
- 4: Blades assembly 5: Retainer Nut
- 6: Drive Socket 7: Switch panel 8: Cushion Pad
- 9: Rubber feet 10: Motorbase
- 11: Overloading switch

### Specifications

Size	190 * 190 * 440 mm
Weight	6.0 kg
Power	2380 W 4.0 HP
Speed	RPM: 45000
Material	Plastic/ Steel
Knives	Carbon Steel
Controls	Manual
Noise reduction	Yes - Pad
CE Certificate	Yes
Container	2.0 l. BPA free



Put ingredients into container and cover it.  
Do not fill above MAX line.

With the unit in STANDBY I position, place container on blender base. Be sure container is fully seated and that drive coupling is properly engaged. Plug blender cord into outlet.

This blender has variable speed controls.  
Set blender to desired speed

Press right paddle switch up to the ON position.

When finished blending, set paddle switch to Standby position.

This blender is equipped with a pulse option.  
Hold left paddle switch in down position to engage pulse function.  
Unit will run on max speed (45,000 RPM) until the paddle switch is released.

Allow motor to come to a complete stop before removing container from blender base.

Never place the container on the motor base or remove it from the motor base while motor is running.

Always hold container with one hand when starting and while blending

Always hold container with one hand when starting and while blending.

Never operate without jar lid.

Wash and dry container after each use.  
Do not wash in dishwasher