



X9000



- 1: Fill Cap 2: Black Lid 3: BPA free Container
- 4: Blades assembly 5: Retainer Nut
- 6: Drive Socket 7: Switch panel 8: Cushion Pad
- 9: Rubber feet 10: Motorbase
- 11: Overloading switch

Specifications

Size	190 * 190 * 440 mm
Weight	6.0 kg
Power	2380 W 4.0 HP
Speed	RPM: 45000
Material	Plastic/ Steel
Knives	Carbon Steel
Controls	Touch
Noise reduction	Yes - Pad
CE Certificate	Yes
Container	2.0 l. BPA free



The keypad has a main power STANDBY button, plus HI , LO, Smoothie button and PULSE button. It has a countdown timer with up and down arrows to set time.

Press the STANDBY button to turn on the blender. Green LED will illuminate. The electronic timer will indicate 10 seconds (default). Press the up or down arrow to set the desired time. The electronic timer will indicate run time in 5-second intervals up to a maximum of 30 seconds. After the desired time is set, press HI or LO to start the blender. The timer will count down to 0 in 1-second intervals and blender will shut off.

If the blender is not used for five seconds, the timer function will turn off and return to manual mode. To reactivate timer, press up or down arrows. When using the electronic timer again, the initial time will be the last time set.

Note: If unit has been turned off or unplugged, the timer will default back to 10 seconds.

For continuous operation, press either LO or HI button. When finished blending, press OFF . For momentary operation, press the PULSE button. Motor will run on HI speed until the button is released.

NOTE: If you want to increase or decrease time while timer is counting down, press up or down arrows. Time will increase or decrease in 5-second intervals.

NOTE: When pressing HI , the unit will start in the LO speed for 2 seconds and then switch to HI speed. This allows for a more even blending of ingredients in container.

Pressing the PULSE button will override the timer and the blender will stop regardless of time left on timer.

Allow motor to come to a complete stop before removing container from blender base. Never place the container on the motor base or remove it from the motor base while motor is running. Wash and dry container after each use.

To turn the unit off, press OFF button. Green LED light will go off.